

Features and Benefits:

- Utilizes 149 MHz technology, developed by the USDA
- Rapid Analysis Mode reduces the need to touch the instrument which saves time in your operational process
- Advanced instrument security protects the GAC 2700-INTL from tampering, adding layers of protection to commercial transactions
- Large 7" touch screen display for greater visibility and responsiveness
- Measurement results in less than 20 seconds
- Modern, intuitive operator interface simplifies training and daily operation
- Memory storage for up to 5,000 measurements
- Multiple USB ports on the front and back of the unit for software upgrades,
 USB devices, printer and peripherals
- Barcode scanner capability to expedite processing time



GAC[™] 2700-INTL Grain Analysis Computer

Calibrations:

With the rich experience in the industry, DICKEY-john® understands the need to tailor the requirements of your region and operation based on the specific application.

- Calibrations specifically developed for specialty crops such as coffee, soybean meal, and many more
- Best-in-class support backed by DICKEY-john's calibration laboratories
- Convenient, easy-to-download calibrations available on www.dickey-john.com
- Custom calibration development available for unique crop and region attributes

Specifications

Operating temperature 2 to 45°C (36 to 113°F)

 Power
 110/220V, 50/60 Hz, 30/35 VA

 Humidity
 20 to 90% non-condensing

 Grain temperature
 -20° to $+45^{\circ}$ C (-4° F to $+113^{\circ}$ F)

depending on grain calibrations

Storage/transit temperature -20 to +60°C (-4 to +140°F)

Moisture range 5 to 45% (grain dependent)

Approximate weight 11.43 kg (25 lbs.)

Approximate dimensions 43.18 cm H x 48.26 cm W x 35.56 cm D

(17" H x 19" W x 14" D)

Languages Dutch, English, French, Hungarian,

Polish, Portuguese, Spanish, Turkish. Specifications subject to change.

Backed by the power of DICKEY-john:

When you buy a DICKEY-john® GAC™ 2700-INTL moisture analyzer you get all the dependability and value you expect from DICKEY-john® products. Like all DICKEY-john® products, the GAC™ 2700-INTL tester is designed and manufactured in the USA, and supported worldwide.

Currently only available in select countries. Specification subject to change.



Intuitive Color Touchscreen



Multiple Back USB Ports



Change seed types with one touch



Easy-to-Read Results Screen