

GAC™ 500XT

Moisture Tester for Coffee Beans

Dual Power Portable Moisture Tester

The GAC™ 500XT moisture tester by DICKEY-john® is a small, portable, and affordable device designed for analyzing moisture. Its versatility in utilizing different power sources enables you to obtain measurements from anywhere across your farming operation. With the GAC™ 500XT moisture tester, you can benefit from the same 2 MHz technology found in the GAC 2100 models.

Features and Benefits:

- Dual power options of 110/220 volt AC or DC power
- Can be powered by a 6V vehicle adapter or a wall power outlet
- Memory for 16 different calibrations
- Provides consistency when running samples
- Eliminates pre-weighing with an internal scale
- Preloaded with 10 languages
- Printer connection capabilities



GAC™ 500XT

Moisture Tester for Coffee Beans

Calibrations

With the rich experience in the industry, DICKEY-john® understands the need to tailor the requirements of your region and operation based on the specific application.

- Custom calibrations available for your specific coffee type and roasting process
- Best-in-class support backed by DICKEY-john's calibration laboratories
- Convenient, easy-to-download calibrations available on www.dickey-john.com
- Custom calibration development available for unique crop and region attributes

Backed by the power of DICKEY-john®:

When you buy a GAC™ 500XT you get all the dependability and value you expect from DICKEY-john® products. DICKEY-john's advanced technology and superior electronics are backed by a team of expert, in-house mechanical, electrical, software, and test engineers.

Specifications

Operating Temperature	41 to 113°F (5 to 45°C)
Power Supply	Wall mount adapter: 90-264 VAC, 47-63 Hz, 0.4A max 6-volt vehicle adapter: 12-24 VDC
Humidity	5 to 95% non-condensing
Grain Temperature	41°F to 113°F (5° to 45°C) depending on grain calibrations
Moisture Range	5 to 45% (grain type dependent)
Approximate Weight	13 lbs (5.78 kg)
Approximate Dimensions	13.5"H x 10.3"W x 13.8"D (34.5 cm H x 26.5 cm W x 35 cm D)
Languages Available (Dependent on region)	English, Spanish, Portuguese, French, German, Italian, Swedish, Finnish, Czech/Slovak, Polish, Serbian/Croatian, Hungarian, Romanian, Turkish, Greek, Bulgarian, Russian
Calibrations	15 different coffee calibrations available including green, roasted, decaf and parchment



Easy to Use Display



Pull Slide to Test Coffee Beans



Release Lever to Dump Coffee Beans